

INSTALLATION, OPERATION AND MAINTENANCE INSTRUCTIONS

KESSEL-lifting station *Aqualift F* (400V) Comfort for wastewater with and without sewage for free-standing installation in frost free rooms

Aqualift F



Aqualift F Duo/XXL



Product Advantages



- Additional inlet connections possible
- Fully automatic operation
- Maintenance-friendly PE-tank
- User friendly 6-line digital display



☐ Installation ☐ Service

of this unit should be carried out by a licensed professional servicer:

Company / Telephone number

Date

Town

1. Safety Information

General safety precautions

During installation, operation, maintenance or repairs to the system, please observe the accident prevention regulations, the applicable DIN and VDE standards and guidelines, and also the regulations of the local energy and supply companies.

The systems may not be operated in explosive areas



Electrical hazards

This system contains electrical voltages and controls rotating mechanical parts. Non-observation of the operating instructions could lead to serious damage, injury or even fatal accidents.

The system must be securely disconnected from the mains supply before commencing any work on it. The local master switch and the cut-outs must be turned off, i.e. switch the system to zero-potential and take precautions to ensure it cannot be switched on again. If only cut-outs are available, these must be switched off and a sign attached to prevent third parties from switching the main fuse on again. VDE 0100 applies to all electrical work on the system.

The control unit and the level control are under voltage and may not be opened. Only electricians may work on the electrical equipment. The term 'electrician' is defined in the VDE 0105.

Steps must be taken to ensure that the electrical cables and all other electrical system parts are in a fully functional condition. If any parts are damaged, the system may not be operated and/or must be immediately shut down.

Risk of burning fingers and hands

The motor may become very hot during operation



Risk of injury to fingers and hands

The pumps are equipped with a closed impeller. Therefore work on the pump may only be carried out if the power supply has been disconnected and the rotating parts have stopped rotating. Take care on sharp edges during maintenance or repair work.

Risk due to heavy weights

The lifting system models with one pump weigh around 45 kg, and with two pumps around 84 kg. The systems may only be lifted or mounted by two persons with appropriate care wearing protective equipment (e.g. protective shoes).

The pumps may only be removed slowly or placed in the pump flange opening by two persons (if suitable precautions to prevent slipping have been taken).

1. Safety Information



Health risk

The wastewater system transports wastewater that contains faeces; in turn this faeces may contain harmful substances. Whenever working on the system, always ensure that there is no direct contact between the wastewater and/or soiled system parts and your eyes, mouth or skin. In the event of direct contact, clean the affected part of your body thoroughly and disinfect if necessary. It is also possible that the atmosphere in the tank may be harmful. Therefore before opening the cleaning aperture (or removing the pump) ensure that the respective room is adequately ventilated or provide for (forced) ventilation during the opening process.

Noise issues

When the pump is operated, a noise level is created that may be a nuisance depending on how the pump is installed. If there are maximum noise level stipulations that need to be observed, appropriate measures need to be taken. The sound damping set from KESSEL may also be helpful here.



Risk of explosion

The inside of the tank is considered to be explosive within the meaning of EN 12050 because the biological digestive process may create flammable gases (hydrogen sulphide, methane gas). Therefore, when unscrewing the pump or the cleaning aperture lid or any other parts, ensure that the room is adequately ventilated or provide for (forced) ventilation during the opening process. Whilst the tank is open, it is forbidden to smoke or carry out any other activities in the respective room that could cause the gas to ignite (e.g. operation of electrical devices without encapsulated motors, metalworking etc.).

Table of contents

1. Safety information	Page	2
2. General	2.1 Area of application.....	Page	5
	2.2 System description	Page	5
3. Technical data	3.1 Aqualift F Duo XXL	Page	6
	3.2 Aqualift F Duo 1,1 kW; 2,2 kW.....	Page	8
	3.3 Instructions for safe use in hazardous areas	Page	9
	3.4 Electric switch unit	Page	10
4. Installation and assembly	4.1 Fitting the collecting tank	Page	11
	4.2 Connecting the pipes.....	Page	11
	4.3 Setting the pressure level switches	Page	13
5. Electrical connections	5.1 General notes.....	Page	14
	5.2 Installation of the switch unit.....	Page	14
	5.3 Installation, wiring	Page	14
	5.4 Control of the flow-direction	Page	16
6. Initial operation	6.1 General notes	Page	16
	6.2 Pressure outlet connecting pieces.....	Page	16
	6.3 Functional description.....	Page	16
	6.4 Functional test	Page	18
7. Inspection and maintenance	7.1 Notes on the pump	Page	21
	7.2 Notes on aeration device	Page	21
	7.3 Notes on the electrical switch unit	Page	22
8. Malfunctions and troubleshooting	8.1 General malfunctions	Page	23
	8.2 Malfunction messages.....	Page	24
9. Control unit	9.1 Switch unit	Page	28
10. Spare parts and accessories	10.1 Accessory parts	Page	30
	10.2 Spare parts	Page	31
11. Warranty	Page	35
12. Declaration of conformity	Page	36
13. Handover certificate	Page	38

2. General

2.1 Area of application



The lifting stations pump wastewater with and without sewage that occurs below the sewer and backwater level fully automatically into the sewage system in accordance with the requirements of DIN 1986. They are only suitable for use for domestic wastewater, for example in single family and multifamily homes, business, hotels and restaurants, department stores, hospitals, schools or similar cases. If the feed to the lifting stations must not be interrupted during normal operation, the lifting station must be equipped with a second pumping device of the same capacity which switches on immediately when required (twin station instead of single station).

The KESSEL lifting station Aqualift® F has been designed for free-standing set-up in frost-protected rooms. The respective switch unit must be installed in a flood-proof, dry and frost-protected room. The wastewater submersible pumps are equipped with a single-channel impeller and have a completely free passage of 40 mm. The pressure pipes must be at least of the size DN 80, the ventilation pipes at least DN 70. Wearing media must be kept away from the pump impeller. The systems are suitable for constant wastewater temperatures up to 35°C. A maximum temperature of 60°C is permissible briefly (up to 10 minutes).

2.2 System description

2.2.1 Aqualift F 1,1 kW/2,2 kW

The KESSEL pumping station Aqualift® F as a single or twin system basically comprises the following assemblies:



- 1. Collecting tank made of PEHD** gas and watertight, with
 - 1.1 One or two wastewater pumps, each of which has a 5 m connection cable
 - 1.2 Pneumatic level control with 5 m air hose each
 - 1.3 Cleaning opening
 - 1.4 Connection for DN 100 inlet pipe
 - 1.5 Connection for DN 70 ventilation pipe
 - 1.6 Connection for manual diaphragm pump DN 32 / 40mm diameter
 - 1.7 DN 100 pressure outlet connecting pieces with integrated backwater flap and aerating device
 - 1.8 Drilling areas

- 2. Electric Control Unit** (see illustrations in chapter 8)

- 3. Accessories** (not illustrated)


- 3.1 Brackets with screws and dowels for fixing the tank to the floor
- 3.2 Rubber hose with hose clamps for the pressure pipe connection
- 3.3 Sound-insulating underlay mat
Mono: Art. no. 28692
Duo: Art. no. 28693

A detailed description of the system set-up can be found in chapter 10, Spare parts.

2. General

3. Technical Data

2.2.2 Aqualift F Duo XXL




- ① DN 150 inlet
- ② DN 100 pressure outlet
- ③ DN 100 ventilation connection
- ④ Twin wastewater pumps each with 5 meter power supply cable
- ⑤ Polyethylene collection tank
- ⑥ Cleanout / Maintenance access
- ⑦ Closure valve
- ⑧ Non-return flap

3.1 Aqualift F Duo XXL

Versions: Aqualift F Duo XXL (twin pumping system) 3.3 kW with DN 100 outlet, order number 28638
Aqualift F Duo XXL (twin pumping system) 4.2 kW with DN 100 outlet, order number 28639
Aqualift F Duo XXL (twin pumping system) 5.6 kW with DN 100 outlet, order number 28640

Performance Curve *Aqualift® F Duo XXL*





- ① 400 V 3,3 kW
- ② 400 V 4,0 kW
- ③ 400 V 5,6 kW

Type	400 V - 3,3 kW	400 V - 4,2 kW	400 V - 5,6 kW
Nominal capacity (P2)	2,6 kW	3,5 kW	4,8 kW
Rated capacity (P1)	3,3 kW	3,3 kW	3,3 kW
Operating voltage	400 V DS	400 V DS	400 V DS
Rated frequency	50 Hz	50 Hz	50 Hz
Nominal current	6,4 A	7,9 A	10,2 A
Connection cable	5 m long, 7 x 1,5 mm²	5 m long, 7 x 1,5 mm²	5 m long, 7 x 1,5 mm²
Temperature of pumping medium	40 °C	40 °C	40 °C
Weight (pump)	30 kg		31 kg
Protection Class rating	IP 68 (24 h /3 mWs)	IP 68 (24 h /3 mWs)	IP 68 (24 h /3 mWs)
Operating mode	S2	S2	S2
	30 Min.	50 Min.	30 Min.
Sound level	< 80 db	< 80 db	< 80 db
Fusing	3 x16 A	3 x 20 A	3 x 25 A
Characteristic C			



3. Technical Data

3.2 Aqualift F 1,1 kW/2,2kW

- *Aqualift F Duo* (twin pump system) 1.1 kW / 2.2 kW with DN 100 pressure outlet



- *Aqualift F Mono* (single pump system) 1.1 kW / 2.2 kW with DN 100 pressure outlet




3. Technical Data

Type	400 V - 1,1 kW	400 V - 2,2 kW
Nominal capacity (P2)	1,15 kW	2,4 kW
Rated capacity (P1)	1,6 kW	3,1 kW
Operating voltage	400 V DS	
Rated frequency	50 Hz	
Nominal current	3,2 A	5,4 A
Start-up current	14,4 A	30,8 A
Fuse	3 x 16 A Charakteristik C	
Connection cable	5 m long, 7 x 1,5 mm ²	
Temperature of material pumped	35 °C	
Weight (pump)	30 kg	31 kg
Protective rating	IP 68 (24h; 3m WS)	
Operating mode	S1 Max. period of perm. operation 240 Min.	S3 30% duty cycler
Sound level	< 70 db	< 70 db
Pump volume	20 l (Mono); 50 l (Duo)	

Table 2

Performance chart



3. Technical Data

3.3 Instruction for proper safe use in explosion endangered areas

Appropriate use

Pump control units are available for single pump as well as twin pump systems. Pump activation is controlled by a pressure sensor. The control unit should not be installed in an area that is designated as an explosion risk.

Classification:

II (1) GD [EEx is] IIC


(Group II, Category (2)G, additional operating parts for gaseous atmospheres)

The requirements of EN 50014:1997 + A1 – A2, EN 50020:2002 have been fulfilled.

EC-type examination certificate of the Zener

BAS 01 ATEX 7217

Description

 II(1) G (EEx ia) IIC CE 1180 Ta = -20 deg C - +60 deg C

Operational Manual

Installation / Commissioning

This wastewater pumping system may only be installed, connection and commissioning by a licensed professional. People operating this system must have knowledge of regulations and codes concerning pumping systems operated in explosion risk areas. Check to insure that the classification of this system (see identification plate on pumping system) meets the on-site requirements.

Allowable operation temperature range of system :

0 dec C to +50 dec C

Twin Pumping System

Circuit ignition protection EEx ia IIC
Connection jacks (OFF, ON1, ON2, ALARM)

MTL 7789+ Protection

Maximum values:

Uo = 28 V

Io = 93 mA

Ro = 300 Ω

Po = 0,33 W

Co = 0,083 μ F

Lo = 16 mH

Lo / Ro = 106 μ H / Ω

Installation instructions

- Please follow all local and national safety regulations
- Please also follow this installation and operational manual

Special requirements for safe operation of this system
None

Maintenance / Servicing

- Opening the control unit cover reduces the protection class (watertightness). Before opening the control unit cover make sure that moisture or splash risk in the area will not effect the control unit. If moisture or splashing could be a risk, make sure to disconnect the control unit from its power source before opening the cover. In general, no moisture, fluids or dirt should ever enter the interior of the control unit. Only a licensed repairman should open the control unit cover
- After any control unit work has taken place, the control unit cover should be closed and properly secured so that the protection class of the control unit is assured.
- No changes to the control unit should be made. Repairs on the control unit are not possible. In the case of a problem with the control unit, please contact the manufacturer.
- If required, system information such as the user's manual, EC Conformity Declarations and other system relevant information can be obtained from the manufacturer.

3. Technical Data

3.4 Electrical Control Unit

3.4.1 General technical data

Ambient conditions

Permissible temperature range:	0 to 50 °C
Permissible air humidity: non-condensing	10 to 80 %
Maximum operating height:	2000 m above sea level
Power consumption max. ca.5 VA for single (electronics without motor)	
Protective class	Class 1
Protective rating	IP 54 when fitted correctly

3.4.2 Supply

Mains supply

PE/N/L1/L2/L3 according to marking on terminal block for
single / twin system

Operating voltage

400 / 230 V 3~ 50 Hz ± 10% rotary current (L1=230V AC /
50Hz±10%for supplying the power packs for the electro-
nics)

Pre-fuse required

For fusing information see Page 6 Table 1 and Page 8
Table 2

3.4.3 Inputs

- Each pump has the circuit TF1
- TF2 is bridged (do not remove bridge)
- Pressure sensor with pressure tube 6 x 4 mm.
- Pressure sensor incoming approx 24 Vda < 5 mA (not
ATEX)
- Pressure sensor incoming (with ATEX) (with XXL Sy-
stems)

3.4.4 Outputs

"Malfunction" relay

Switcher; opener, middle contact, closer each with max 42
V ac/dc 0.5A for 'malfunction' and 'warning' relay; external
power should be separately fused

**CAUTION! When power switch OFF, power still sup-
plied to unit!**

Relay 'Warning'

Switcher, opener, middle contact, closer each with max
42 V ac/dc 0.5 Amp.

Motor (single system) Motor PE Mains connection (spring connection on board) Motor U T1 contactor Motor V T2 contactor Motor W T3 contactor	}	max. 4kW
--	---	----------

Motor 1/2 (twin system) Motor 1/2 PE mains connection (spring connection on board) Motor 1/2 U T1 contactor 1/2 Motor 1/2 V T2 contactor 1/2 Motor 1/2 W T3 contactor 1/2	}	max. 4kW
--	---	----------

4. Installation and assembly

The following parts are included in the scope of supply (see section 2.2):

- Collecting tank with all components mounted
- Electric switch unit
- Accessory parts

IMPORTANT:

The electric switch unit must be stored frost-free and dry. If the system is not connected directly to the power supply on installation, the switch unit inc. all electric parts must be stored accordingly.

CAUTION:

Hazard through heavy weights.

The lifting stations weigh approx. 45 kg (single system) and approx 84 kg (twin system). The parts may only be lifted and/or assembled using suitable equipment and exercising appropriate caution. If the systems are dropped, this can lead to irreparable damage to the system parts (e.g. pump) or the whole system. Such damage is not covered by the warranty.

Site of Installation


The KESSEL Aqualift F wastewater lifting station is designed for free standing installation in a frost protected room. The included control unit should be installed in a dry, frost free and flood protected area.

4.1 Fitting the collecting tank

Maintenance work on the lifting stations, they must always be installed in such a way that there is sufficient access to all areas of the lifting station and replacement of all components is guaranteed. According to DIN 12056, there must be at least 60 cm space all round the system (on all sides and above it) to meet this requirement.

The system must be set up at the appropriate spot in the room, aligned horizontally and placed on practical sound-insulating material (available as an accessory from KESSEL). The brackets, screws and dowels must be used to fix the liftingstation to the floor to prevent movement or twisting.

INSTALLATION SITE: The KESSEL lifting station Aqualift® F has been designed for free-standing set-up in frost-protected rooms. The respective switch unit must be installed in a flood-proof, dry and frost-protected room.



4.2 Pipe connections

All pipes must be routed so that they drain freely with gravity. All pipe connections must be flexible and sound insulated.

There are two types of connections possible:

I. Use of existing preformed inlets on the pump body (for connection of inlet pipe, ventilation and manual diaphragm pump according to Fig. A and B) by cutting off the "front cap" as shown in Fig. C.




Illustration A: Single Pump System





Illustration B: Twin Pump System


4. Installation and assembly

A standard plastic pipe with gasketed socket can be pushed over the inlet connection on the pump body (see Illustration C).

Alternatively, the connection of a plastic pipe with DN 100 for the inlet or DN 70 for ventilation can be carried out using connection clamps or rubber connection couplings. To prevent damage to the pipe when tightening clamps or coupling screws, a steel re-enforcement ring should be placed inside the inlet connection (see Illustration D.)




ill. C:



ill. D:

II. Connecting pipes to drilled out additional inlet holes on side of pump body (for inlet pipe or manual diaphragm pipe connection) using hole saw. Appropriate pipe inlet gasket should be fit into previously cut out inlet hole, interior portion of gasket should be lubricated and then pipe should be push fit (see Illustration. E)



ill. E

* KESSEL-Accessory parts

4. Installation and assembly

IMPORTANT

In the case of all the connections drilled at the side it must be remembered that the level control is adjusted in such a way that during normal operation the water level in the container only reaches up to or just below the lower edge of the moulded inlet pipe connecting piece on the side. For this reason, a respective water level will result in all pipes that are connected lower down. In the case of inlet pipes this means that dirt deposits cannot be excluded and may lead to the pipe becoming blocked in extreme situations.

● Inlet pipe

The inlet pipe must be laid with a downward slope / gradient to the KESSEL lifting station in accordance with DIN 1986 and be routed as straight as possible. Connection to the tank can be carried out as described in Section I or II above.

The ventilation pipe sets up pressure compensation to the fresh air for the air flowing into or out of the system during emptying or filling. According to DIN 1986 the size of the ventilation pipe must be at a minimum DN 50 for these lifting stations and must be routed over the roof to avoid odour problems.

Connection to the tank can be carried out as described in Section I or II above.

● Pressure pipe

The pressure pipe for directing the soiled water into the sewage system must be connected directly to the respective pressure pipe connection. According to the regulations of EN 12056, the outlet pressure pipe must be laid above the backwater level and connected to a ventilated drainage pipe.

The rubber hose included in the scope must be pushed about 4 cm over the pressure connecting piece at the pressure connection and fixed in place using a hose clamp as a means of acoustic insulation and to prevent transmission of forces. Connection of the rubber hose is not an interlocking connection.

It must be set up on site using brackets. The pressure pipe must be connected (see above) in such a way that no forces are transferred to the system and there is no direct contact with the building (structure-borne noise). No other drainage fixtures may be connected to the pressure pipe.

Air-tightness and material strength must be guaranteed under pressure load, too. This must be checked during initial operation.

The pressure pipe must have a flexible connection to the building to prevent water hammer forces from being transferred to the building. When cast metal or steel pressure pipes with low absorption properties are used, a water hammer arrestor must be included in the pressure pipe from pumping heights from 5 m.

Pressure resistant non-return flaps available as accessories: DN 80 backwater flap made of cast iron (art. no.: 206-199)

DN 100 backwater flap made of cast iron (art. no.: 206-198)
Aerating device (art. no. 206-200)

A shut-off valve must be installed in the pressure pipe on site in accordance with EN 12056. For this, we recommend the non-return valves for mono systems (art. no. 28683) and for duo systems (art. no. 28694) from the KESSEL range of accessories.

4.3. Level measurement

Level measurement takes place using a pressure sensor and submersible pipe. The transparent air hose must always be routed rising to the switch unit so that no condensation can collect in the air hose. Perfect function is only guaranteed when permanent pressure compensation takes place between the switch unit and lifting station. Excess air hose lengths must be shortened. The switching levels are pre-set and can be changed using the switch unit. More detailed information is available from KESSEL Customer Services.



● Aqualift F XXL Models

Float switch settings

Float switches on the Aqualift F XXL lifting stations have been installed and set at the factory. Do not attempt to change the location or level of these float switches as it will only lead to problems with the operation of the lifting station.

Four float switches are included in the XXL lifting stations (pump off, pump 1 on, pump 2 on and alarm). The alarm level is approximately the same height as the inlet level of the lifting station.

In the case that different activation levels are required, the float switches need to be adjusted accordingly. It is important that the alarm level float switch activation level is not set higher than the base of the inlet level and also that the Off float switch is not set too low to prevent the pump from pumping too low and intaking air.

5. Electrical connections

Attention:

Only qualified electricians may carry out the work on electrical equipment described below. Before any work is carried out on the control unit, the pump or level control, the main power supply to the lifting station must be turned off and fuses must be switched off, i.e. be voltage-free and secured against being accidentally re-activated during service work.

5.1 General instructions

An external main switch must be installed for the electric switch unit that can be used in an emergency to switch off all the downstream circuits independently of the control unit. This must be assigned clearly to the switch unit. All connected cables must be strain-relieved. Screw connections not used must always be sealed properly.

IMPORTANT:

All the cables connected to the electrical switch unit must be fixed in place using suitable measures (e.g. cable ties) so that they do not cause a hazard in the 1-error case, i.e. if a connection becomes loose.

Please heed national and local safety regulations. If these are not observed, personal hazard may be the result. In addition, no liability or warranty will be granted. After work has been completed, the housing cover must be sealed properly again.

In the case that the lifting station has a pressure sensor, the cable for this sensor should be laid separately from the power cable and the pump cable in order to insure proper operation of the pressure sensor.

5.2 Mounting the switch unit

Screw the housing cover with max. 1 Nm. Install the switch unit provided in a frost-free, dry, flood-proof and well-ventilated room. The switch unit has been designed for vertical wall-mounting on a solid base. Sufficient air circulation in the room of installation must be insured to prevent excessive temperatures. The unit is mounted using 4 screws (Ø 6 mm) at the corners of the housing (drilling template in the packaging box). The mounting holes are accessible after the cover has been fully opened.

5.3 Installation, wiring

The pump cable and pressure sensor cables have a standard length of 5 m. The pump cable may be extended by using a VDE certified extension connection. In the case that the pressure sensor cable is to be extended, the extension connection must be completely air tight and the cable must be run in a positive slope from the lifting station to the control unit (no loops or kinks).

5. Electrical connections

The individual connection jobs are listed in the following table and in the connection diagrams on pages 27 and 29. The explanations in chapter 8, Electric switch unit, must also be heeded (position of the control elements, view of the inside of the switch unit).

SINGLE PUMP LIFTING STATION – please follow all safety instructions and regulations!	
Work to be completed	Description
Battery connection	<ul style="list-style-type: none"> Both batteries (2 x 9V) must be connected on the board.
Mains connection	<ul style="list-style-type: none"> Connect the mains supply cable L1 / L2 / L3 / N / PE at the terminal block using screw connection. N and PE always have to be connected. The required fusing must not exceed 16 Amps for each phase. An improper connection (Phase and N improperly connected for example) will activate the integrated fuse (315 mA)
Motor power cable	<ul style="list-style-type: none"> Connect the motor supply cable U/V/W to the connector in the right direction in the lower screw terminals T1 / T2 / T3. The direction of rotation of the motor must be heeded. PE must be connected with TF1 and TF2 to the terminal block on the board underneath the motor protection switch.
Motor temperature sensor	<ul style="list-style-type: none"> Wire 4 of the motor power cable must be connected to the lowest terminal of the terminal block TF2-TF1. Wire 5 of the motor power cable must be connected to the middle terminal of the terminal block TF2 TF1. The input TF2 is bridged with a 2-pole jumper, i.e. the middle terminal is double occupied. Jumper must not be removed!
Level measurement	<p><u>Connection to the pressure sensor</u></p> <p>The transparent air hose must always be laid with a positive slope to the control unit (no loops or kinks in the cable). The connection of the air sensing hose to the control unit must be firmly and properly connected.</p>
Outputs "Malfunction" and "alarm / warning"	<ul style="list-style-type: none"> The "malfunction" and "warning" messages are issued via a relay (changeover contact) without protective circuit. Inductive loads must be de-jammed externally. The quiescent state (currentless) of the relays is printed on the circuit board. It means "malfunction" and "warning" message is switched on. 42 V DC/ 0.5 A

5. Electrical connections

TWIN PUMP LIFTING SATION – please follow all safety instructions and regulations!	
Work to be completed	Description
Battery connection	<ul style="list-style-type: none">Both batteries (2 x 9V) must be connected on the board.
Mains connection	<ul style="list-style-type: none">Connect the mains supply cable L1 / L2 / L3 / N / PE at the terminal block using screw connection.N and PE always have to be connected.The required fusing must not exceed 16 Amps for each phase.An improper connection can damage or destroy the control unit.
Motor power cable	<ul style="list-style-type: none">Connect both the motor supply cables U/V/W to the connector in the right direction in the lower screw terminals T1 / T2 / T3 (Pump 1 left, Pump 2 right). The direction of rotation of the motor must be heeded.PE must be connected with TF1 and TF2 to the terminal block on the board underneath the motor protection switch (Pump 1 left, Pump 2 right).
Motor temperature sensor	<ul style="list-style-type: none">For both pump 1 and 2 - Wire 4 of the motor power cable must be connected to the lowest terminal of the terminal block TF2 TF1. Wire 5 of the motor power cable must be connected to the middle terminal of the terminal block TF2 TF1.Input TF2 Pump 1 and Pump 2 is bridged with a 2-pole jumper, i.e. the middle terminal is double occupied. Jumper must not be removed!
Level measurement	<p><u>Connection to the pressure sensor</u></p> <p>The transparent air hose must always be laid with a positive slope to the control unit (no loops or kinks in the cable). The connection of the air sensing hose to the control unit must be firmly and properly connected.</p>
Outputs "Malfunction" and "alarm / warning"	<ul style="list-style-type: none">The "malfunction" and "warning" messages are issued via a relay (changeover contact) without protective circuit. Inductive loads must be de-jammed externally. The quiescent state (currentless) of the relays is printed on the circuit board. It means "malfunction" and "warning" message is switched on.42 V DC/ 0.5 A

5.4 Checks

- Setting of motor protection switch

The motor protection switches must be set to the values for rated current of the respective pumps as specified in section 3.

6. Initial operation

6.1 General instructions

Initial operation

Initial operation must be carried out by a qualified expert, with the direct supplier of the wastewater lifting station responsible for his availability. During initial operation, a test run with water is required over at least two switching cycles. During the test run, dry running must be avoided. Before, during and after this test run, the following must be checked:

- The electric fuse protection of the wastewater lifting station according to IEC or local regulations
- The direction of rotation of the motor
- The gate (actuation, open position, air-tightness)
- The switching and setting of switching heights in the collecting tank, in as far as these are not pre-set by the manufacturer
- Air-tightness of the system, fittings and pipes
- Check on operating voltage and frequency
- Functional test on the backflow preventer
- Malfunction warning device
- Attachment of the pressure pipe
- Motor protection switch; check by briefly screwing individual fuses out (two-phase run)
- Oil level (if oil chamber exists)
- Pilot lamps and counters
- Functional test for any manual pump that may be installed.

Initial operation must be documented in writing, whereby important data e.g. setting of the motor protection switch and status of operating hours counter must be noted.

This initial operation may only be carried out by authorised specialist staff.

DIN 1986, part 3, must be heeded during the initial operation of lifting stations.

CAUTION:

Before initial operation the inlet pipes and the pumps must be cleaned of solid materials such as metal, sand etc.

Before initial operation the pump must be filled with pumping fluid up to the height of the ventilation bore hole of the pump housing.

The pump must not intake air!

After the complete and correct installation of the complete system and all the additional parts as well as the pipe and electrical installations, the system can be put into operation. Any shut-off valves must be opened. Make sure before you put the system into operation that the nominal voltage and type of current specified for the system correspond to the nominal voltage and type of current on site.


Check the system installation/cabling carefully before you put the system into operation. Is the protective earthed conductor working? Have the relevant standards/guidelines been heeded, particularly with a view to the potentially explosive area? DO NOT put the system into operation if there is any damage to the motor, switch unit or cables visible. Always follow the safety instructions in chapter 1 of this manual

IMPORTANT:


All screw connections must be checked for a tight fit.

6.2 Pressure outlet connecting pieces

The pressure outlet connecting pieces of the lifting stations are equipped with a backwater flap with aerating device as standard for each pump. The aerating device must always be in operating position (see Fig. 1).



The flap (dotted line) is opened exclusively by the pumping flow of the pump.





6.3 Operating the control unit (from model year 01/10)

The lifting station is operational when the POWER LED light is on and no error or malfunctions (ALARM LED) are displayed. As the wastewater level rises in the tank, the increased air pressure is sensed by the pressure sensor which in turn will activate the pump. As the pump pumps out wastewater the pressure will be reduced inside the tank and as soon as the pressure falls below the ON level, the pressure switch will signal to the control unit to turn off the pump – the pump will stop running after the post run time of the pump has elapsed.

In the case the the pump runs longer than the pre-set maximum pump run time, the pump will automatically turn off and a warning message will be shown via the orange LED on the control unit and the warning relay will activate. The warning message and the warning relay activation will be stored until the 'Alarm' button has been pressed – only after this has occurred can the pump(s) begin operating again. The pump(s) can be manually activated by pressing the 'Pump Test' button twice.

6. Initial operation

6.4 Control unit operation



When power is initially connected to the control unit, a basic system check is automatically conducted which includes 4 basic points. In the digital display, the following is shown:

1. Language desired for control unit operation
2. Current date and time
3. Level sensor type
4. Type of pumps in lifting station (kW)

By using the up and down cursor buttons on the control unit, the desired setting can be chosen by pressing the OK button. As soon as all 4 settings have been selected, the control unit loads the settings into the memory and then places the lifting station into operation. The lifting station is now fully operational.

6. Initial operation

Control unit digital display instructions

The digital display operation is in the system information as well as in three separate main menu sections. Pressing one of the control unit buttons will automatically back light the digital display.

OK-Button: confirms the setting and enters into the next setting level

ESC-Button: returns the control unit to the previous setting / step



Navigation within a level



An alarm signal can be confirmed and muted by pressing the Alarm button once. In the case that the error has been fixed, pressing the Alarm button again will also erase the optical LED warning light.

In the case that the error has not been fixed, pressing the Alarm button again will cause the audible alarm to re-activate


During a power outage, the pumping system is not operational – the control unit will go into stand-by mode meaning battery operation. This is signalled by an audible and

optical alarm. The audible alarm can be confirmed and cancelled by pressing the Alarm button. The control unit will run for at least 72 hours in stand-by mode. When the 72 hour period is over, the control unit will automatically turn itself off. In the case that power is returned within 1 hour, the control unit will return to operation in the same mode it was in when the power failure occurred. If this is not the case, the control unit will perform an automated re-commissioning when power is restored. This can also be accomplished by pressing the Alarm button for an extended period.

Note:

Certain control unit display menus / levels are password protected. This protects the unit from improper operation.

6.4.1 System-Menu




Beispiel:

0.	Systeminfo	_____	display of level including number
Pump:	,1kW	_____	Lifting station type
Floater:		_____	sensor type
24.12.2009	20:45:16	_____	Date and Time
Level:	130mm	_____	current wastewater level

6. Initial operation

6.4.2 Information menu



Operating hours

Displays all running times of the system.

Events / errors

Chronological error and event display (see also Chapter 10 "Malfunctions and troubleshooting")

All modifications to the settings are saved here.

Control type

Displays the output parameters and the sensor configuration incl. combinations:

- pressure sensor (pressure)
- alarm
- compressor (comp.)
- float

Maintenance date

Shows the next and the last maintenance date.

Note: Dates are only available if they have been filed in the 'Settings' menu by the servicing partner.


Current measured values

Displays the mains voltage, current, battery voltage and filling level.

Parameter

Displays all the system control parameter settings: Mains-ON delay, height of the dynamic pressure bell, switch-on lock, measuring range, ON1 level.

6.4.3 Maintenance menu



Manual operation

In manual mode, the automatic mode is deactivated.


Self-diagnosis system (SDS)

System test similar to initialisation.

Maintenance date

The next maintenance date is entered by the servicing partner.

6.4.4 Settings menu



Only authorised maintenance staff may change the settings. To do this, the KESSEL Customer Service must be contacted for the password.

7. Inspection and maintenance

The system must be inspected once a month by the operator with regard to serviceability and leaks by observing a switching cycle.

CAUTION:

Always disconnect the system from the mains supply before servicing! Observe the safety instructions!

Only authorised qualified persons may carry out the inspection and maintenance tasks described below.

Repairs may only be carried out by the manufacturer.

When servicing lifting systems, the DIN 1986, Part 3 must be observed. Maintenance must be carried out regularly by authorised qualified persons.

IMPORTANT:

All screws may only be tightened with a maximum force of 3 Nm.

The following tasks must be carried out:

- Visual inspection of the entire system, the pumps and the fittings
- Thorough cleaning of the entire system and the pump
- Inspection of the entire system and pump casing for external damage and visible wear
- Inspection of the pump to ensure it runs smoothly and for wear and deposits
- Inspection of the connection lines for mechanical damage and wear
- Inspection of the seal connections for leaks; in the event of recognisable wear, exchange the seals (e.g. O-ring)
- Check the insulation on the pump motor
- If necessary test the function of the manual closure valve.
- The check valve must be replaced after 2 years service.

7.1 Information about the pump


The pump should be inspected at regular intervals. When the operating noises become louder or there are vibrations in the pipe system, the pump casing and impeller need to be checked for any ingrained dirt or wear.

To do this, unscrew the four attachment screws on the motor unit and remove from the pump casing.


When inspecting the pump casing, note that the venting borehole must remain open under all operating conditions.

7.2 Information about the backflow preventer

The backflow preventer can be used to completely empty the pressure line by manually lifting the check valve of the lifting system. To do this, turn the flap opener with a size 8 (15 mm) wrench and hold (see Fig. 2) until the pressure line is empty. After this, the flap opener must be returned to its original position or the marked operating setting (see Fig. 3).



III. 2




III. 3


Note:

When the screw connections on the lower and upper flange of the valve casing are unscrewed, the entire valve casing can be removed for cleaning and maintenance purposes. Of course before this happens the pressure line must be blocked and drained.

7. Inspection and maintenance



Threaded hole for easy pump disassembly.



7.3 Information about the electrical switchgear

- The battery is a wear part and should be checked once a year and exchanged if necessary. Ensure that the replaced battery is disposed of correctly in an environmentally compatible manner. It may only be replaced with a battery of the same type.
- The contactor is a wear part and should be checked once a year and exchanged if necessary. Ensure that the replaced battery is disposed of correctly in an environmentally compatible manner. It may only be replaced with a battery of the same type.
- After the maintenance work the switchgear lid must be closed again correctly (contact protection!).
- Repairs may only be carried out by the manufacturer.

8. Malfunctions and troubleshooting

The following trouble shooting and checks should only be performed by qualified service workers. When in doubt please contact the KESSEL Customer Service Department or the authorized company who originally installed the system.

8.1 General malfunctions

	Malfunction	Cause	Remedial measure
1	Pumps do not start	Motor protection switch has triggered, motor is blocked	Remove pump; eliminate blockage (object) in the impeller or housing area
		Motor turns sluggishly	Maintenance / repair by Customer Services
		1 or 2 phases have no current Control fails on account of heavy fluctuations in the mains power supply	Check fuses and power supply cables
		Phases are reversed	Check proper phase connection and swap if required
		Pressure sensor not airtight or PE hose not connected	Check all screw connections for air-tightness
2	Pumps are running but alarm level is reached	Too much wastewater entering system	Check to see if unusually large amount of wastewater are entering the system – if required temporarily stop draining specific drainage fixtures into the lifting station, if possible, disconnect drainage fixtures connected to the lifting station
		Pump performance is not sufficient	<ul style="list-style-type: none"> • Remove any obstructions located in impeller or pump housing • Remove any obstructions located in outlet or outlet assembly • Pumps no longer offer original performance, replace pumps • Lifting station was improperly specified and is not designed for the site's requirements – contact KESSEL Customer Service Department
		Ventilation setting may not be in operation mode	Set non-return flap in closed position (operational position)
3	Wastewater does not drain away – lowest fixtures connected to lifting station are flooded.	Lifting station not properly set	Turn main control unit power switch to the 'ON' position
		Power cable to control unit not receiving power	Check power supply to control unit – check fuses
		Wastewater level sensing system not operational	Check level sensor for blockages and check for proper operation
		Main inlet pipe to lifting station blocked	Check and clean main inlet pipe if necessary
		Gate closure valve to lifting station (if existing) may be closed or only partially open	Check to make sure gate closure valve (if existing) is in the fully open position
		Wastewater temperature entering lifting station over extended period of time (15 minutes) too high.	Reduce temperature of wastewater entering lifting station
4	Lifting station suddenly begins operating loudly	Pump may be damaged due to foreign objects	Check pump for damage and fix / replace if necessary
		Foreign object may be located in intake / impeller area	Check intake area and impeller for foreign object. Remove objects or replace pump if necessary.

8. Malfunctions and troubleshooting

	Malfunction	Cause	Remedial measure
5	Smelly odour during operation	Lifting station is not water tight / air tight	Check ventilation, inlet, pressure outlet and cover for water tightness – repair if required.
		Pump is not water tight	Check pumps – if required have customer service repair or replace pump(s)
	Sharp odour during operation	Motor is too hot – overloaded	Check motor and impeller for free, easy operation / rotation. Make sure motor protection switch is operational
			Too frequent pump operation due to excessive wastewater levels – contact KESSEL Customer Service
6	Lifting station turns on too frequently, pumps start without reason	Protectors too hot due to faulty level switching	Check pump for pump activation problems
		Wastewater amount entering lifting station too high	Check wastewater amounts entering system and correct if necessary
		Lifting station non-return valve not operating correctly – wastewater which was pumped out of the system is flowing back into the system after pumps stop due to malfunctioning non-return valve.	Check non-return valve in outlet of lifting station for blockage or malfunction. Clean or replace if necessary.
7	Lifting station operates continuously or displays switching malfunctions	Foam build up inside lifting station body	Reduce amount of soap, detergent and shampoo entering the lifting station
		Station body / pump(s) effected by heavy grease / fat build up	Clean entire lifting station, reduce amounts of oils / greases entering lifting station
		Ventilation pipe blocked	Check pressure sensor cable between lifting station and control unit.
		Pressure sensor system clogged or blocked, switching levels incorrectly set.	Make sure cable is not kinked or coiled in a loop. Continuous slope from lifting station to control unit is required (not loops or kinks). Fix or replace if necessary. Remove pressure sensor system and clean. Check pressure controls and levels
8	Lifting station not pumping out sufficient wastewater amounts	Phases incorrectly connected	Swap phase connections to control unit
		Pump rotation backwards	Check pump power supply cables for proper connection

8.2 Warning messages

All warning message will be displayed on the control unit. In the case that multiple warning messages occur at one time – individual warning messages can be read by scrolling down the control unit's digital display.

8. Malfunctions and troubleshooting

Error messages / troubleshooting

● = lit up ○ = off ◐ = slow flashing ⊗ = fast flashing

Battery error

Mono	
◐ POWER-LED	
◐ ALARM-LED	
○ NIVEAU-LED	
○ PUMPE-LED	

- acknowledge alarm and alarm key
- check if the battery is connected
- exchange discharged battery
- the charging status of the batteries can be tested in menu 1.5.3 (battery power check)
- after acknowledging the signal tone, press the alarm key again
 - > switchgear continues to work without the batteries
 - > no protective function during power outage

Duo	
◐ POWER-LED	
◐ ALARM-LED	
○ PUMPE I-LED	
○ PUMPE II-LED	

Mains failure (battery mode)

Mono	
○ POWER-LED	
⊗ ALARM-LED	
○ NIVEAU-LED	
○ PUMPE-LED	

- Check if the mains failure has just affected the room or the entire building
- Check the cut-outs / check the error current circuit breaker
- Check if the mains supply cable is defective
- Check the micro fuse in the switchgear (only use a fuse with the same rated value and tripping characteristics).

Duo	
○ POWER-LED	
⊗ ALARM-LED	
○ PUMPE I-LED	
○ PUMPE II-LED	

Motor error

Mono	
⊗ POWER-LED	
⊗ ALARM-LED	
○ NIVEAU-LED	
⊗ PUMPE-LED	

Cause: TF1, TF2, motor circuit breaker

Remedy:

- If display shows "Motor circuit breaker 1/2"
 - > check the motor circuit breaker 1/2

Duo Pompe 1	
⊗ POWER-LED	
⊗ ALARM-LED	
⊗ PUMPE I-LED	
○ PUMPE II-LED	

- If display shows "TF1a / TF2a"
 - > the lower winding temperature switch has triggered
 - > resets automatically when the motor cools down

Error message must be acknowledged with the alarm key.

- If display shows "TF1b / TF2b"
 - > for lifting systems, bridge TF2 defective/not installed

Duo Pompe 2	
⊗ POWER-LED	
⊗ ALARM-LED	
○ PUMPE I-LED	
⊗ PUMPE II-LED	

Exchange/install bridge

8. Malfunctions and troubleshooting

Limit running time error / limit running count error

Mono	
●	POWER-LED
◐	ALARM-LED
○	NIVEAU-LED
◐	PUMPE-LED

- Limit running count error: Pump is activated more than 20 times in 3 min
 - > Check the air pipe between the immersion tube/immersion bell and switchgear for water inclusions
 - > Check if the immersion tube/immersion bell is blocked
 - > Check intake, check pump capacity

Duo Pumpe 1	
●	POWER-LED
◐	ALARM-LED
◐	PUMPE I-LED
○	PUMPE II-LED

- Limit running time error: Pump runs for longer than 240 min without stopping
 - > Check the air pipe between the immersion tube/immersion bell and switchgear for water inclusions
 - > Check if the immersion tube/immersion bell is blocked
 - > Check intake, check pump capacity

Duo Pumpe 2	
●	POWER-LED
◐	ALARM-LED
○	PUMPE I-LED
◐	PUMPE II-LED

Sensor error (only for XXL-systems)

Mono	
●	POWER-LED
◐	ALARM-LED
◐	NIVEAU-LED
○	PUMPE-LED

- Level error:
A float indicates a level although no float below has triggered (wrong sequence float)
 - > Check the float cable of the float below
 - > Check the function of the float in the tank (lift)
 - > The pump(s) is/are switched on.
The switchgear works with the recognised level.

Duo Pumpe 1/2	
●	POWER-LED
◐	ALARM-LED
○	PUMPE I-LED
○	PUMPE II-LED

Revolving field / phase errors

Mono	
⊗	POWER-LED
⊗	ALARM-LED
⊗	NIVEAU-LED
⊗	PUMPE-LED

- Revolving field error:
Wrong revolving field when connected to mains Switchgear
 - > exchange 2 phases

Duo Pumpe 1/2	
⊗	POWER-LED
⊗	ALARM-LED
⊗	NIVEAU-LED
⊗	PUMPE-LED

- Phase error:
Phase L1 or L2, L3 do not exist
 - > Check connection to switchgear, power cable, cut-outs,
Check error current circuit breaker
 - > If L1 fails, the revolving field direction cannot be recognised.
 - > If L1 fails, the switchgear goes into battery mode
 - > In the case of revolving field errors, the pumps are not switched on in manual or automatic mode

8. Malfunctions and troubleshooting

Relay switching cycles

Mono	
●	POWER-LED
◐	ALARM-LED
○	NIVEAU-LED
◑	PUMPE-LED

Main contactor has exceeded 100,000 switching cycles
--> can be acknowledged, main contactor does another 1000 switching cycles before a new message is sent
--> Exchange the contactor --> Contact the Customer Service
--> After 100000 switching cycles the relay switching cycle error is repeated after every further 1000 cycles

Duo Pumpe 1	
●	POWER-LED
◐	ALARM-LED
◑	PUMPE I-LED
○	PUMPE II-LED

Duo Pumpe 1	
●	POWER-LED
◐	ALARM-LED
○	PUMPE I-LED
◑	PUMPE II-LED

Relay error

Mono	
●	POWER-LED
⊗	ALARM-LED
○	NIVEAU-LED
⊗	PUMPE-LED

Main contactor no longer switches off
--> Disconnect the switchgear from the mains
--> Exchange the contactor --> Contact the Customer Service

Duo Pumpe 1	
●	POWER-LED
⊗	ALARM-LED
⊗	PUMPE I-LED
○	PUMPE II-LED

Duo Pumpe 2	
●	POWER-LED
⊗	ALARM-LED
○	PUMPE I-LED
⊗	PUMPE II-LED

Alarm level exceeded


Mono	
●	POWER-LED
●	ALARM-LED
○	NIVEAU-LED
○	PUMPE-LED

Alarm level is achieved by the water level
--> Alarm turns off automatically if the alarm level has been undercut again
--> LED only turns off after it has been acknowledged manually
--> Check intake
--> Check level recording and switch points


Duo Pumpe 1	
●	POWER-LED
●	ALARM-LED
○	PUMPE I-LED
○	PUMPE II-LED

9. Control unit

9.1.1 Switch unit (single pump system) (from model year 01/10)




9.1.2 Switch unit (double pump system) (from model year 01/10)



9. Control unit

9.1.3 Switch unit (double pump system) Aqualift XXL



10. Spare parts and accessories

10.1 Accessories


<i>Description</i>	<i>Order Number</i>
Emergency manual hand pump	28680
Closure valve for emergency manual hand pump	28681
Flexible coupling with twin securing brackets	DN 40 28660
	DN 70 28661
	DN 100 28663
Flange – pipe connection	DN 80 28655
	DN 150 28658
Plastic closure valve for non-pressure piping	DN 100 28698
	DN 150 28699
Vibration mat (for under lifting station)	Single pump station 28692
	twin pump station 28693
Pipe inlet sealing gasket	DN 50 850114
	DN 70 850116
	DN 100 850117
	DN 125 850118
	DN 150 850119
Hole saw drill bit DN 50 - DN 150	50100
Battery (quantity 1)	197-081
Closure valve for single pump system	DN 100 28683
Closure valve for twin pump system	DN 100 28694
Compressor for air pressure sensor allows more reliable air pressure operation	28048
Air filter for compressor (28048)	363-140
Motor protection switch 2.5 – 4 Amp	363-134
Motor protection switch 4 – 6.3 Amp.	363-135
Motor protection switch 6.3 – 10 Amp	363-136
Protector	363-151
Level sensor	363-138
Float switch for Aqualift F XXL Systems	185-043
Motor (complete) for 2.6 kW Aqualift F XXL System	245-401
Motor (complete) for 3.5 kW Aqualift F XXL System	245-402
Motor (complete) for 5.6 kW Aqualift F XXL System	245-406
Control unit for Aqualift F XXL 2.6 kW pump lifting station (ATEX)	363-132
Control unit for Aqualift F XXL 2.6 kW pump lifting station	363-177
Control unit for Aqualift F XXL 3.5 kW pump lifting station (ATEX)	363-176
Control unit for Aqualift F XXL 3.5 kW pump lifting station	363-178
Control unit for Aqualift F XXL 5.6 kW pump lifting station (ATEX)	363-196
Control unit for Aqualift F XXL 5.6 kW pump lifting station	363-197

see also KESSEL-Catalog

10. Spare parts and accessories

10.2 Replacement Parts


10.2.1 Single Pump lifting station



Pos.	Quantity	Order-Nr.	Name
1	1	206-004	Single pump tank
2	1	206-161	Pump flange – complete
3a	1	367-002	Motor (complete) 1.1 kW / 400V
3b	1	367-003	Motor (complete) 2.2 kW / 400V
4	1	240-051	Outlet assembly with non-return flap – DN 100
5	1	206-208	Pressure sensor for single pump systems
6	1	206-018	Access cover
7	1	363-104	Control unit Komfort (1.1 kW)
	1	363-105	Control unit Komfort (2.2 kW)
8	1	28663	DN 100 connection coupling
9	2	206-054	Securing brackets
10	1	206-042	Flange gasket
11	1	049-010	Gasket
12	1	049-011	Gasket
13	1	049-005	O-ring
14	4	017-095	Screws
15	8	206-074	PT-screws
16	8	017-199	M8 x 25 screws
17	8	017-012	Washer
18	1	367-007	Gasket
19	1	206-228	PE air pressure tube 6 x 4 mm (5 meter length)
19	1	206-227	PE air pressure tube 6 x 4 mm (10 meter length)

10. Spare parts and accessories


10.2.2 Twin Pump lifting station



Pos.	Quantity	Order-Nr.	Name
1	1	206-005	Twin pump tank
2	2	206-161	Pump flange – complete
3a	2	367-002	Motor (complete) 1.1 kW / 400V
3b	2	367-003	Motor (complete) 2.2 kW / 400V
4	1	240-056	Outlet assembly with non-return flap – DN 100
5	1	206-224	Pressure sensor for twin pump systems (beginning 01/ 2010)
6	1	206-018	Access cover
7a	1	363-121	Control unit Komfort for twin pump sytem (1.1 kW)
7b	1	363-122	Control unit Komfort for twin pump system (2.2 kW)
8	1	28663	DN 100 connection coupling
9	2	003-144	Pipe clamp D = 120 for DN 100
10	2	206-054	Securing brackets
11	2	206-042	Flange gasket
12	1	049-010	Gasket
13	1	049-011	Gasket
14	2	049-005	O-ring
15	8	017-095	Screws
16	4	206-074	PT-screws
17	14	017-199	M8 x 25 screws
18	14	017-012	Washer
20	4	017-213	Gasket
22	1	206-228	PE air pressure tube 6 x 4 mm (5 meter length)
22	1	206-227	PE air pressure tube 6 x 4 mm (10 meter length)

10. Spare parts and accessories


10.2.3 Air pressure sensor L = 175 mm



Single pump systems (206-208)
Twin pump systems (206-224)

Pos.		Order nr.	Name
1	1	197-333	Screw cap
2	1	197-340	Clamping ring
3	1	197-339	Fastening nut.
	1	206-228	PE air pressure tube 6 x 4 mm (5 m)
	1	206-227	PE air pressure tube 6 x 4 mm (10 m)


10.2.5 Single pump outlet assembly with non-return flap (240-051)



Pos.		Order-Nr.	Name
1	1	240-046	Outlet housing
2	1	240-048	Connection tip
3	1	240-038	Securing bolts
4	1	240-037	O-ring
5a	1	240-068	Non-return flap for 1.1 kW pump models
5b	1	240-069	Non-return flap for 2.2 kW pump models

10. Spare parts and accessories

10.2.6 Single pump outlet assembly with non-return flap



Pos.	Quantity	Order-Nr.	Name
1	2	240-007	Outlet housing
2	2	240-045	Outlet housing cover
3	1	240-009	T-connection DN 100
4a	2	240-068	Non-return flap for 1.1 kW pump models
4b	2	240-069	Non-return flap for 2.2 kW pump models
6	4	240-027	O-ring
7	8	240-058	M6 screw
8	8	240-059	M6 bolt
9	8	240-038	M8 screw
10	8	240-039	M8 bolt
11	2	049-005	DN 125 O-ring

11. Warranty

1. In the case that a KESSEL product is defective, KESSEL has the option of repairing or replacing the product. If the product remains defective after the second attempt to repair or replace the product or it is economically unfeasible to repair or replace the product, the customer has the right to cancel the order / contract or reduce payment accordingly. KESSEL must be notified immediately in writing of defects in a product. In the case that the defect is not visible or difficult to detect, KESSEL must be notified immediately in writing of the defect as soon as it is discovered. If the product is repaired or replaced, the newly repaired or replaced product shall receive a new warranty identical to that which the original (defective) product was granted. The term defective product refers only to the product or part needing repair or replacement and not necessarily to the entire product or unit. KESSEL products are warranted for a period of 24 month. This warranty period begins on the day the product is shipped from KESSEL to its customer. The warranty only applies to newly manufactured products. Additional information can be found in section 377 of the HGB.

In addition to the standard warranty, KESSEL offers an additional 20 year warranty on the polymer bodies of class I / II fuel separators, grease separators, inspection chambers, wastewater treatment systems and rainwater storage tanks. This additional warranty applies to the watertightness, usability and structural soundness of the product.

A requirement of this additional warranty is that the product is properly installed and operated in accordance with the valid installation and user's manual as well as the corresponding norms / regulations.

2. Wear and tear on a product will not be considered a defect. Problems with products resulting from improper installation, handling or maintenance will also be considered a defect.

Note: Only the manufacturer may open sealed components or screw connections. Otherwise, the warranty may become null and void

01.06.2010



EU-KONFORMITÄTSERKLÄRUNG **EC declaration of conformity/ Déclaration CE de conformité**

Nach der Maschinenrichtlinie 2006/42/EG, der Niederspannungsrichtlinie 2006/95/EG,
Richtlinie der elektromagnetischen Verträglichkeit 89/336/EWG.
According to the Machine Guidelines 2006/42/EG, the Low Voltage Guidelines 2006/95/EG,
Electromagnetism Guidelines 89/336/EEC.
Selon les directives mécaniques 2006/42/EG, les directives de basse tension 2006/95/EG,
les directives pour la compatibilité électromagnétique 89/336/EEC

KESSEL AG
Bahnhofstraße 31
D-85101 Lenting

erklären wir, / we declare, / nous déclarons,

dass das Produkt/ that the product/ que le produit

KESSEL- Hebeanlage *Aqualift® F*
für fäkalienhaltiges und fäkalienfreies Abwasser zur freien Aufstellung in
frostgeschützten Räumen

KESSEL *Aqualift® F* Lifting Station for wastewater with or without sewage
for above ground installation in weather protected areas.

Poste de relevage *Aqualift® F* KESSEL
pour eaux usées et eaux vannes pour une installation en local à l'abri du gel

den folgenden Normen entspricht:/ is in agreement with/ est en accord avec:

EN 12050-1, EN 12056-4, EN 55082-2, EN 55014, EN 292, EN 55011, EN 60335

Lenting, den 23.2.2010


M. Rinckens

Leiter Innovationsmanagement / Dokumentationsverantwortlicher
Innovation Management Manager / Responsible for Documentation
Responsable du management pour innovation et de la documentation


E. Thiemt

Vorstand
Managing Board
Conseil d'administration



Note

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

13. Important contacts / Info

Separator Type: _____

Day / Hour _____

Project description /Building services supervisor _____

Address _____

Telephone / Fax _____

Builder _____

Address _____

Telephone / Fax _____

Planner _____

Address _____

Telephone / Fax _____

Contracted plumbing company _____

Address _____

Telephone / Fax _____

KESSEL-Commissions no.: _____

System operator /owner _____

Address _____

Telephone / Fax _____

User _____

Address _____

Telephone / Fax _____

Person of delivery _____

Other remarks _____

The system operator, and those responsible, were present during the commissioning of this system.

Place and date

Signature owner

Signature user



Handover-Ceritfficate

Handover certificate (copy for the company carrying out the installation)

- ☐ The initial operation and instruction was carried out in the presence of the person authorised to perform the acceptance and the system operator.
- ☐ The system operator/person authorised to perform the acceptance was informed about the obligation to service the product according to the enclosed operating instructions.
- ☐ Initial operation and instruction were not carried out.

The client/ person responsible for initial operation was handed the following components and/or product components

Initial operation and instruction is being carried out by (company, address, contact, phone)


The exact coordination of the dates for initial operation/instruction is being carried out by the system operator and person responsible for initial operation.

Place, date

Signature of person authorised to perform acceptance

Signature of system operator

Signature of the company carrying out the installation work



- ☐ Backwater protection
- ☐ Lifting Stations and pumps
- ☐ Drains and shower channels
- ☐ Separators
 - Grease Separators
 - Oil-/Fuel-/Coalescence Separators
 - Starch Separators
 - Sediment Separators
- ☐ Septic Systems
- ☐ Inspection Chambers
- ☐ Rainwater Management Systems

 **KESSEL**